
Telescopic Sliding Frameless Glass 4 Door System Installation Instructions


Installation Instructions:

Notice:


- 1. This system can not be installed in all hidden slot, must have enough space to install.
- 2. The rail must be installed on steel girders or reinforced concrete in enough strong.
- 3. Please clean the inside of rail without any foreign matter , then put roller hardware inside.
- 4. We suggest customer ask serviceman to inspect the sliding door if it is used frequently.


Installation Tools:







Accessories list









3 Left Linkage door diagram




4 Right Linkage door diagram








5-1 Example of the door's dimensions calculation The calculation of Left side example 1 and Right side 1 is the same





6-1 Example of the door's dimensions calculation The calculation of Left side example 2 and Right side 2 is the same
























Please put the B door into A's bottom guide, as the picture shown.


Door open direction

Flat round screws M5X12

M5*12 hexagonal screws

(G)





$15\,$ Adjust C door 's trigger ,A door and B door 's stopper.

Adjust the K stopper and trigger L according the installation situation.

